
Round Core String Installation

1. Measure approx. 5-6" AFTER the machine head for the string you are ready to cut.





2. Bend the string you are ready to cut at AT LEAST a 90 degree angle.

3. Cut the string just AFTER the bend.





4. The cut string...

5. Insert the sting all the way into the machine head.





6. Make sure the string wraps around the machine head as shown - at least 4 times.