



1. Input "mono-jack"
2. Output "mono-jack"
3. Power supply DC 12V/100mA. Attention! - you've got to connect Power supply delivered with you effect. [max power consumption 75mA]
4. **Vintage-MIX-Modern** - triple mode switch of drive charcter - for your disposal classic "Vintage" sound, extreme "Modern" and "Mix" between "Vintage" & "Modern" sound.
5. **DRIVE** - drive level knob.
6. **LEVEL** - boost effect level knob.
7. **BASS** - bass level knob
8. **TREBLE** - treble level knob
9. **Footswitch**. If it's turned off true-bypass is active.
10. Power led.