

800JP (Jazzplate)

The 800JP preamp borrows the EQ section of the famous GK800RB amplifier and squeezes it into an onboard preamp, loaded into a Jazzplate, for you Jazz bass lovers.

This tone stack has some serious high frequency power and a very deep bottom end, just like the amplifier its based on.

The Hi-mid and Treble controls are highly interactive; same goes for the Lo-Mid and Bass controls.

A new feature, the **Contour** Switch, has been added to this new model. It acts as a pre-shape EQ that scoops the mids therefore changing the overall tone spectrum.


This Jazzplate comes in two options; Neck Volume and Bridge Volume or Master Volume and Blend.

Installation and Warranty: This is a solderless preamp. Any tampering with the preamp (ex: soldering or unsoldering directly on the preamp or any of its components) can result in Warranty void.

!!!!MAKE SURE THE JACK IS FULLY INSERTED!!!


-**Treble**: Boost and Cut around 4khz -**Hi- Mid**: Boost and Cut at around 1khz -**Bass**: Boost and Cut at around 250Hz

Voltage: 9 to 27VDC Current Draw: 3mAh (9v)



Red: + battery red wire

Black: - battery black wire




B= Hot from
Bridge pickup
GND for Bridge
pickup

N= Hot from Neck pickup GND for Neck pickup



- 1- From Jack Tip (follow the colour) colour)
- 2- From Jack Sleeve (follow the colour)
- 3- From Jack Ring (follow the colour)
- 4- Extra Ground



www.lusithanddevices.com

nuno@lusithanddevices.com

Warranty and Conditions: Any of our products, that are defective, will be replaced/ fixed and all expenses will be covered once it has been verified that the problem isn't a result of bad handling or negligence on the owners part. If the damage is due to negligence or wrong handling, warranty is lost and a cost can ocurr fior the devices repair (the shipping costs will not be covered on such cases).

Warranty is valid for 2 years after the date of purchase.